嵌入式系统实验

——安装 httpd+php+mysql

在 PCDuino 上安装 httpd+php+mysql 环境。

实验目的

- 1. 熟悉 pcDuino 在 linux 下软件的安装;
- 2. 掌握 httpd、php、mysql 的安装与配置。

实验器材

硬件

- pcDuino v2 板一块;
- 5V/1A 电源一个;
- microUSB 线一根;
- USB-TTL 串口线一根(FT232RL 芯片或 PL2303 芯片)。

以下为自备(可选)器材:

- PC (Windows/Mac OS/Linux) 一台;
- 以太网线一根(可能还需要路由器等)。

软件

- PC 上的 USB-TTL 串口线配套的驱动程序;
- PC 上的串口终端软件,如 minicom、picocom、putty等;
- PC 上的 SSH 软件,如 putty 等。

实验步骤

1. 在 pcDuino 上安装并配置 apache;

利用命令行 apt-get install apache2 下载并安装 apache

```
root@Acadia:/mnt# sudo apt-get install apache2
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following extra packages will be installed:
    apache2-mpm-worker apache2-utils apache2.2-bin apache2.2-common libaprl
    libaprutill libaprutill-dbd-sqlite3 libaprutill-ldap
Suggested packages:
    apache2-doc apache2-suexec apache2-suexec-custom ufw
Recommended packages:
    ssl-cert
The following NEW packages will be installed:
    apache2 apache2-mpm-worker apache2-utils apache2.2-bin apache2.2-common
    libapr1 libaprutill libaprutill-dbd-sqlite3 libaprutill-ldap
O upgraded, 9 newly installed, O to remove and O not upgraded.
Need to get 1590 kB of archives.
After this operation, 4209 kB of additional disk space will be used.
Do you want to continue [Y/n]? []
```

选择继续完成 apache 的下载和安装。安装完成后,设置 apache 的默认端口为 80(在 apache2.conf 文件中)。

```
root@Acadia:/mnt# sudo vi /etc/apache2/apache2.conf
ServerName localhost:80

# # Based upon the NCSA server configuration files originally by Rob McCool.

# This is the main Apache server configuration file. It contains the # configuration directives that give the server its instructions.

# See http://httpd.apache.org/docs/2.2/ for detailed information about # the directives.
```

2. 验证 apache 已经安装并能成功访问:

利用 wget 命令访问 localhost 获得 html 文件

```
root@Acadia:/mnt# wget http://localhost
--2015-03-19 23:57:04-- http://localhost/
Resolving localhost (localhost)... 127.0.0.1, ::1
Connecting to localhost (localhost)|127.0.0.1|:80... connected.
HTTP request sent, awaiting response... 200 OK
Length: 177 [text/html]
Saving to: `index.html'
```

打开该文件可见访问成功(It works!)

3. 在 pcDuino 上安装并配置 php;

```
root@Acadia:/mnt# sudo apt-get install libapache2-mod-php5 php5
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following extra packages will be installed:
    apache2-mpm-prefork php5-common
Suggested packages:
    php-pear php5-suhosin
Recommended packages:
    php5-cli
The following packages will be REMOVED:
    apache2-mpm-worker
The following NEW packages will be installed:
    apache2-mpm-prefork libapache2-mod-php5 php5-common
```

4. 写一个 php 脚本验证 php 已经安装成功;

在 var/www 目录下创建简单的 php 脚本文件,如下:

```
root@Acadia:/mnt# cd /var/www
root@Acadia:/var/www# vi test.php
<html>
<body>
<?php
echo 'hello world!';
?>
</body>
</html>
```

利用 wget 命令访问该文件,显示结果如下,成功显示 hello world!字样,可见 php 功能运作正常。

5. 在 pcDuino 上安装并配置 mysql;

利用 apt-get 命令安装 mysql 以及 php5-mysql, 如下:

```
root@Acadia:/mnt# sudo apt-get install mysql-server
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following extra packages will be installed:
   libdbd-mysql-perl libdbi-perl libmysqlclient18 libnet-daemon-perl
   libplrpc-perl mysql-client-5.5 mysql-client-core-5.5 mysql-common
   mysql-server-5.5 mysql-server-core-5.5
Suggested packages:
   libterm-readkey-perl tinyca mailx
Recommended packages:
   libhtml-template-perl
The following NEW packages will be installed:
   libdbd-mysql-perl libdbi-perl libmysqlclient18 libnet-daemon-perl
   libplrpc-perl mysql-client-5.5 mysql-client-core-5.5 mysql-common
   mysql-server mysql-server-5.5 mysql-server-core-5.5
```

```
root@Acadia:/mnt# sudo apt-get install php5-mysql
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following NEW packages will be installed:
   php5-mysql
O upgraded, 1 newly installed, O to remove and O not upgraded.
Need to get 61.5 kB of archives.
```

其中,对 mysql 进行简单的密码设置

Configuring mysql-server-5.5
Repeat password for the MySQL "root" user:

<0k>

重启后更新配置

6. 写一个 php 脚本访问 mysql, 验证 mysql 安装成功。

在 var/www 目录下编写如下的 php 脚本测试 mysql 是否安装成功

```
root@Acadia:/var/www# vi testsql.php
<html>
<body>
<?php
$con = mysql_connect("localhost", "root", "159357");
if(!$con) echo "Fail to connect!";
else echo "Success to connect!";
?>
</body>
</html>
```

访问该脚本测试能够成功连接 mysql